

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>2CG</b>	As of 2013	ENGINE	√	√	√	√
<b>2CG</b>	As of 2013	AT	√	√	√	√
<b>2CG</b>	As of 2013	ABS	√	√	√	√
<b>2CG</b>	As of 2013	SRS	√	√	√	√
<b>ACCORD</b>	Up to 1998	PGM-FI	√	√	√	√
<b>ACCORD</b>	Up to 1998	SRS	√	√	√	√
<b>ACCORD</b>	1999 - 2003	PGM-FI	√	√	√	√
<b>ACCORD</b>	1999 - 2003	AT	√	√	√	√
<b>ACCORD</b>	1999 - 2003	ABS	√	√	√	√
<b>ACCORD</b>	1999 - 2003	SRS	√	√	√	√
<b>ACCORD</b>	1999 - 2003	EPS	√	√	√	√
<b>ACCORD</b>	As of 2004	PGM-FI	√	√	√	√
<b>ACCORD</b>	As of 2004	AT	√	√	√	√
<b>ACCORD</b>	As of 2004	ABS	√	√	√	√
<b>ACCORD</b>	As of 2004	SRS	√	√	√	√
<b>ACCORD</b>	As of 2004	BCM	√	√	√	√
<b>ACCORD</b>	As of 2004	IMA(HYBRID)	√	√	√	√
<b>ACCORD</b>	As of 2004	HONDA SMART CART KEY	√	√	√	√
<b>ACCORD</b>	As of 2004	IMMOBILISE	√	√		√
<b>ACTY</b>	1992 - 2003	PGM-FI	√	√	√	√
<b>ACTY</b>	1992 - 2003	SRS	√	√	√	√
<b>ACTY</b>	As of 2004	PGM-FI	√	√	√	√
<b>ACTY</b>	As of 2004	ABS	√	√	√	√
<b>ACTY</b>	As of 2004	SRS	√	√	√	√
<b>ACTY</b>	As of 2004	IMMOBILISE R	√	√		√
<b>ACURA EL</b>	As of 1999	PGM-FI	√	√	√	√
<b>ACURA EL</b>	As of 1999	AT	√	√	√	√
<b>ACURA EL</b>	As of 1999	ABS	√	√	√	√
<b>ACURA EL</b>	As of 1999	SRS	√	√	√	√
<b>ACURA EL</b>	As of 1999	IMMOBILISE R	√	√		√
<b>ACURA CL</b>	As of 1999	PGM-FI	√	√	√	√
<b>ACURA CL</b>	As of 1999	AT	√	√	√	√
<b>ACURA CL</b>	As of 1999	ABS	√	√	√	√
<b>ACURA CL</b>	As of 1999	SRS	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
ACURA CL	As of 1999	IMMOBILISE R	√	√		√
ACURA CSX	As of 1999	PGM-FI	√	√	√	√
ACURA CSX	As of 1999	AT	√	√	√	√
ACURA CSX	As of 1999	ABS	√	√	√	√
ACURA CSX	As of 1999	SRS	√	√	√	√
ACURA CSX	As of 1999	IMMOBILISE	√	√		√
ACURA MDX	As of 1999	PGM-FI	√	√	√	√
ACURA MDX	As of 1999	AT	√	√	√	√
ACURA MDX	As of 1999	ABS	√	√	√	√
ACURA MDX	As of 1999	SRS	√	√	√	√
ACURA MDX	As of 1999	VTM-4	√	√	√	√
ACURA MDX	As of 1999	SH-AWD	√	√	√	√
ACURA MDX	As of 1999	IMMOBILISE R	√	√	√	√
ACURA RDX	As of 1999	PGM-FI	√	√	√	√
ACURA RDX	As of 1999	AT	√	√	√	√
ACURA RDX	As of 1999	ABS	√	√	√	√
ACURA RDX	As of 1999	SRS	√	√	√	√
ACURA RDX	As of 1999	IMMOBILISE R	√	√		√
ACURA RSX	As of 1999	PGM-FI	√	√	√	√
ACURA RSX	As of 1999	AT	√	√	√	√
ACURA RSX	As of 1999	ABS	√	√	√	√
ACURA RSX	As of 1999	SRS	√	√	√	√
ACURA RSX	As of 1999	IMMOBILISE R	√	√		√
ACURA TSX	As of 1999	PGM-FI	√	√	√	√
ACURA TSX	As of 1999	AT	√	√	√	√
ACURA TSX	As of 1999	ABS	√	√	√	√
ACURA TSX	As of 1999	SRS	√	√	√	√
ACURA TSX	As of 1999	IMMOBILISE	√	√		√
AIRWAVE	As of 1999	PGM-FI	√	√	√	√
AIRWAVE	As of 1999	AT	√	√	√	√
AIRWAVE	As of 1999	ABS	√	√	√	√
AIRWAVE	As of 1999	SRS	√	√	√	√
AIRWAVE	As of 1999	EPS	√	√	√	√
AIRWAVE	As of 1999	IMMOBILISE	√	√		√
ASCOT	As of 1999	PGM-FI	√	√	√	√
ASCOT	As of 1999	SRS	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
AVANCIER	As of 1999	PGM-FI	√	√	√	√
AVANCIER	As of 1999	AT	√	√	√	√
AVANCIER	As of 1999	ABS	√	√	√	√
AVANCIER	As of 1999	SRS	√	√	√	√
AVANCIER	As of 1999	IMMOBILISE R	√	√		√
CAPA	As of 1999	PGM-FI	√	√	√	√
CAPA	As of 1999	AT	√	√	√	√
CAPA	As of 1999	ABS	√	√	√	√
CAPA	As of 1999	SRS	√	√	√	√
CAPA	As of 1999	IMMOBILISE	√	√		√
CIIMO	As of 2012	ENGINE	√	√	√	√
CIIMO	As of 2012	AT	√	√	√	√
CIIMO	As of 2012	ABS	√	√	√	√
CIIMO	As of 2012	SRS	√	√	√	√
CITY	As of 1999	PGM-FI	√	√	√	√
CITY	As of 1999	AT	√	√	√	√
CITY	As of 1999	ABS	√	√	√	√
CITY	As of 1999	SRS	√	√	√	√
CITY	As of 1999	EPS	√	√	√	√
CITY	As of 1999	IMMOBILISE	√	√		√
CIVIC	Up to 2004	PGM-FI	√	√	√	√
CIVIC	Up to 2004	AT	√	√	√	√
CIVIC	Up to 2004	ABS	√	√	√	√
CIVIC	Up to 2004	SRS	√	√	√	√
CIVIC	Up to 2004	EPS	√	√	√	√
CIVIC	Up to 2004	IMA(HYBRID)	√	√	√	√
CIVIC	Up to 2004	IMMOBILISE R	√	√		√
CIVIC	As of 2005	PGM-FI	√	√	√	√
CIVIC	As of 2005	AT	√	√	√	√
CIVIC	As of 2005	ABS	√	√	√	√
CIVIC	As of 2005	SRS	√	√	√	√
CIVIC	As of 2005	EPS	√	√	√	√
CIVIC	As of 2005	BCM	√	√	√	√
CIVIC	As of 2005	IMMOBILISE	√	√		√
CIVIC	As of 2005	IMA(HYBRID)	√	√	√	√
CIVIC	As of 2005	HYDRAULIC BOOSTER	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>CIVIC</b>	As of 2005	i-SHIFT	√	√	√	√
<b>CR-V</b>	Up to 2003	PGM-FI	√	√	√	√
<b>CR-V</b>	Up to 2003	AT	√	√	√	√
<b>CR-V</b>	Up to 2003	ABS	√	√	√	√
<b>CR-V</b>	Up to 2003	SRS	√	√	√	√
<b>CR-V</b>	As of 2004	PGM-FI	√	√	√	√
<b>CR-V</b>	As of 2004	AT	√	√	√	√
<b>CR-V</b>	As of 2004	ABS	√	√	√	√
<b>CR-V</b>	As of 2004	SRS	√	√	√	√
<b>CR-V</b>	As of 2004	BCM	√	√	√	√
<b>CR-V</b>	As of 2004	IMMOBILISE	√	√		√
<b>CR-X/delsol</b>	As of 1999	PGM-FI	√	√	√	√
<b>CR-X/delsol</b>	As of 1999	AT	√	√	√	√
<b>CR-X/delsol</b>	As of 1999	ABS	√	√	√	√
<b>CR-X/delsol</b>	As of 1999	SRS	√	√	√	√
<b>CR-X/delsol</b>	As of 1999	IMMOBILISE	√	√		√
<b>CRIDER</b>	As of 2013	ENGINE	√	√	√	√
<b>CRIDER</b>	As of 2013	AT	√	√	√	√
<b>CRIDER</b>	As of 2013	ABS	√	√	√	√
<b>CRIDER</b>	As of 2013	SRS	√	√	√	√
<b>CROSSROAD</b>	As of 1999	PGM-FI	√	√	√	√
<b>CROSSROAD</b>	As of 1999	AT	√	√	√	√
<b>CROSSROAD</b>	As of 1999	ABS	√	√	√	√
<b>CROSSROAD</b>	As of 1999	SRS	√	√	√	√
<b>CROSSROAD</b>	As of 1999	EPS	√	√	√	√
<b>CROSSROAD</b>	As of 1999	IMMOBILISE R	√	√		√
<b>DOMANI</b>	As of 1999	PGM-FI	√	√	√	√
<b>DOMANI</b>	As of 1999	AT	√	√	√	√
<b>DOMANI</b>	As of 1999	ABS	√	√	√	√
<b>DOMANI</b>	As of 1999	SRS	√	√	√	√
<b>DOMANI</b>	As of 1999	IMMOBILISE R	√	√		√
<b>EDIX</b>	As of 1999	PGM-FI	√	√	√	√
<b>EDIX</b>	As of 1999	AT	√	√	√	√
<b>EDIX</b>	As of 1999	ABS	√	√	√	√
<b>EDIX</b>	As of 1999	SRS	√	√	√	√
<b>EDIX</b>	As of 1999	IMMOBILISE	√	√		√
<b>ELEMENT</b>	As of 1999	PGM-FI	√	√	√	√
<b>ELEMENT</b>	As of 1999	AT	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>ELEMENT</b>	As of 1999	ABS	√	√	√	√
<b>ELEMENT</b>	As of 1999	SRS	√	√	√	√
<b>ELEMENT</b>	As of 1999	IMMOBILISE	√	√		√
<b>ELYSION</b>	As of 1999	PGM-FI	√	√	√	√
<b>ELYSION</b>	As of 1999	AT	√	√	√	√
<b>ELYSION</b>	As of 1999	ABS	√	√	√	√
<b>ELYSION</b>	As of 1999	SRS	√	√	√	√
<b>ELYSION</b>	As of 1999	BCM	√	√	√	√
<b>ELYSION</b>	As of 1999	HONDA SMART CART KEY	√	√	√	√
<b>ELYSION</b>	As of 1999	IMMOBILISE	√	√		√
<b>FIT</b>	As of 1999	PGM-FI	√	√	√	√
<b>FIT</b>	As of 1999	AT	√	√	√	√
<b>FIT</b>	As of 1999	ABS	√	√	√	√
<b>FIT</b>	As of 1999	SRS	√	√	√	√
<b>FIT</b>	As of 1999	EPS	√	√	√	√
<b>FIT</b>	As of 1999	IMMOBILISE	√	√		√
<b>FR-V</b>	As of 1999	PGM-FI	√	√	√	√
<b>FR-V</b>	As of 1999	AT	√	√	√	√
<b>FR-V</b>	As of 1999	ABS	√	√	√	√
<b>FR-V</b>	As of 1999	SRS	√	√	√	√
<b>FR-V</b>	As of 1999	EPS	√	√	√	√
<b>FR-V</b>	As of 1999	IMMOBILISE R	√	√		√
<b>HR-V</b>	As of 2014	ENGINE	√	√	√	√
<b>HR-V</b>	As of 2014	AT	√	√	√	√
<b>HR-V</b>	As of 2014	ABS	√	√	√	√
<b>HR-V</b>	As of 2014	SRS	√	√	√	√
<b>INSIGHT</b>	As of 1999	PGM-FI	√	√	√	√
<b>INSIGHT</b>	As of 1999	AT	√	√	√	√
<b>INSIGHT</b>	As of 1999	ABS	√	√	√	√
<b>INSIGHT</b>	As of 1999	SRS	√	√	√	√
<b>INSIGHT</b>	As of 1999	IMMOBILISE	√	√		√
<b>INSPIRE</b>	As of 1999	PGM-FI	√	√	√	√
<b>INSPIRE</b>	As of 1999	AT	√	√	√	√
<b>INSPIRE</b>	As of 1999	ABS	√	√	√	√
<b>INSPIRE</b>	As of 1999	SRS	√	√	√	√
<b>INSPIRE</b>	As of 1999	IMMOBILISE	√	√		√
<b>INTEGRA</b>	As of 1999	PGM-FI	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>INTEGRA</b>	As of 1999	AT	√	√	√	√
<b>INTEGRA</b>	As of 1999	ABS	√	√	√	√
<b>INTEGRA</b>	As of 1999	SRS	√	√	√	√
<b>INTEGRA</b>	As of 1999	IMMOBILISE	√	√		√
<b>JADE</b>	As of 2014	ENGINE	√	√	√	√
<b>JADE</b>	As of 2014	AT	√	√	√	√
<b>JADE</b>	As of 2014	ABS	√	√	√	√
<b>JADE</b>	As of 2014	SRS	√	√	√	√
<b>JAZZ</b>	As of 1999	PGM-FI	√	√	√	√
<b>JAZZ</b>	As of 1999	AT	√	√	√	√
<b>JAZZ</b>	As of 1999	ABS	√	√	√	√
<b>JAZZ</b>	As of 1999	SRS	√	√	√	√
<b>JAZZ</b>	As of 1999	EPS	√	√	√	√
<b>JAZZ</b>	As of 1999	IMMOBILISE	√	√		√
<b>LAGREAT</b>	As of 1999	PGM-FI	√	√	√	√
<b>LAGREAT</b>	As of 1999	AT	√	√	√	√
<b>LAGREAT</b>	As of 1999	ABS	√	√	√	√
<b>LAGREAT</b>	As of 1999	SRS	√	√	√	√
<b>LAGREAT</b>	As of 1999	EPS	√	√	√	√
<b>LAGREAT</b>	As of 1999	IMMOBILISE	√	√		√
<b>LEGEND</b>	As of 1999	PGM-FI	√	√	√	√
<b>LEGEND</b>	As of 1999	AT	√	√	√	√
<b>LEGEND</b>	As of 1999	ABS	√	√	√	√
<b>LEGEND</b>	As of 1999	SRS	√	√	√	√
<b>LEGEND</b>	As of 1999	IMMOBILISE	√	√		√
<b>LIFE</b>	As of 1999	PGM-FI	√	√	√	√
<b>LIFE</b>	As of 1999	AT	√	√	√	√
<b>LIFE</b>	As of 1999	ABS	√	√	√	√
<b>LIFE</b>	As of 1999	SRS	√	√	√	√
<b>LIFE</b>	As of 1999	IMMOBILISE	√	√		√
<b>LOGO</b>	As of 1999	PGM-FI	√	√	√	√
<b>LOGO</b>	As of 1999	AT	√	√	√	√
<b>LOGO</b>	As of 1999	ABS	√	√	√	√
<b>LOGO</b>	As of 1999	SRS	√	√	√	√
<b>LOGO</b>	As of 1999	IMMOBILISE R	√	√		√
<b>MOBILIO</b>	As of 1999	PGM-FI	√	√	√	√
<b>MOBILIO</b>	As of 1999	AT	√	√	√	√
<b>MOBILIO</b>	As of 1999	ABS	√	√	√	√
<b>MOBILIO</b>	As of 1999	SRS	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>MOBILIO</b>	As of 1999	IMMOBILISE	√	√		√
<b>MR-V</b>	As of 1999	PGM-FI	√	√	√	√
<b>MR-V</b>	As of 1999	AT	√	√	√	√
<b>MR-V</b>	As of 1999	ABS	√	√	√	√
<b>MR-V</b>	As of 1999	SRS	√	√	√	√
<b>MR-V</b>	As of 1999	IMMOBILISE	√	√		√
<b>NSX</b>	As of 1999	PGM-FI	√	√	√	√
<b>NSX</b>	As of 1999	AT	√	√	√	√
<b>NSX</b>	As of 1999	ABS	√	√	√	√
<b>NSX</b>	As of 1999	SRS	√	√	√	√
<b>NSX</b>	As of 1999	IMMOBILISE	√	√		√
<b>N-BOX</b>	As of 2012	ENGINE	√	√	√	√
<b>N-BOX</b>	As of 2012	AT	√	√	√	√
<b>N-BOX</b>	As of 2012	ABS	√	√	√	√
<b>N-BOX</b>	As of 2012	SRS	√	√	√	√
<b>ODYSSEY</b>	Up to 2003	PGM-FI	√	√	√	√
<b>ODYSSEY</b>	Up to 2003	AT	√	√	√	√
<b>ODYSSEY</b>	Up to 2003	ABS	√	√	√	√
<b>ODYSSEY</b>	Up to 2003	SRS	√	√	√	√
<b>ODYSSEY</b>	As of 2004	PGM-FI	√	√	√	√
<b>ODYSSEY</b>	As of 2004	AT	√	√	√	√
<b>ODYSSEY</b>	As of 2004	ABS	√	√	√	√
<b>ODYSSEY</b>	As of 2004	SRS	√	√	√	√
<b>ODYSSEY</b>	As of 2004	BCM	√	√	√	√
<b>ODYSSEY</b>	As of 2004	IMMOBILISE	√	√		√
<b>ORTHIA</b>	As of 1999	PGM-FI	√	√	√	√
<b>ORTHIA</b>	As of 1999	AT	√	√	√	√
<b>ORTHIA</b>	As of 1999	ABS	√	√	√	√
<b>ORTHIA</b>	As of 1999	SRS	√	√	√	√
<b>ORTHIA</b>	As of 1999	IMMOBILISE	√	√		√
<b>PARTNER</b>	As of 1999	PGM-FI	√	√	√	√
<b>PARTNER</b>	As of 1999	AT	√	√	√	√
<b>PARTNER</b>	As of 1999	ABS	√	√	√	√
<b>PARTNER</b>	As of 1999	SRS	√	√	√	√
<b>PARTNER</b>	As of 1999	IMMOBILISE R	√	√		√
<b>PILOT</b>	As of 1999	PGM-FI	√	√	√	√
<b>PILOT</b>	As of 1999	AT	√	√	√	√
<b>PILOT</b>	As of 1999	ABS	√	√	√	√
<b>PILOT</b>	As of 1999	SRS	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>PILOT</b>	As of 1999	TPMS	√	√	√	√
<b>PILOT</b>	As of 1999	IMMOBILISE	√	√		√
<b>PRELUDE</b>	As of 1999	PGM-FI	√	√	√	√
<b>PRELUDE</b>	As of 1999	AT	√	√	√	√
<b>PRELUDE</b>	As of 1999	ABS	√	√	√	√
<b>PRELUDE</b>	As of 1999	SRS	√	√	√	√
<b>PRELUDE</b>	As of 1999	IMMOBILISE R	√	√		√
<b>RAFAGA</b>	As of 1999	PGM-FI	√	√	√	√
<b>RAFAGA</b>	As of 1999	AT	√	√	√	√
<b>RAFAGA</b>	As of 1999	ABS	√	√	√	√
<b>RAFAGA</b>	As of 1999	SRS	√	√	√	√
<b>RAFAGA</b>	As of 1999	IMMOBILISE R	√	√		√
<b>RIDGELINE</b>	As of 1999	PGM-FI	√	√	√	√
<b>RIDGELINE</b>	As of 1999	AT	√	√	√	√
<b>RIDGELINE</b>	As of 1999	ABS	√	√	√	√
<b>RIDGELINE</b>	As of 1999	SRS	√	√	√	√
<b>RIDGELINE</b>	As of 1999	IMMOBILISE R	√	√		√
<b>S-MX</b>	As of 1999	PGM-FI	√	√	√	√
<b>S-MX</b>	As of 1999	AT	√	√	√	√
<b>S-MX</b>	As of 1999	ABS	√	√	√	√
<b>S-MX</b>	As of 1999	SRS	√	√	√	√
<b>S-MX</b>	As of 1999	IMMOBILISE R	√	√		√
<b>S2000</b>	As of 1999	PGM-FI	√	√	√	√
<b>S2000</b>	As of 1999	SRS	√	√	√	√
<b>SABER</b>	As of 1995	ENGINE	√	√	√	√
<b>SABER</b>	As of 1995	AT	√	√	√	√
<b>SABER</b>	As of 1995	ABS	√	√	√	√
<b>SABER</b>	As of 1995	SRS	√	√	√	√
<b>SHUTTLE</b>	As of 1999	PGM-FI	√	√	√	√
<b>SHUTTLE</b>	As of 1999	AT	√	√	√	√
<b>SHUTTLE</b>	As of 1999	ABS	√	√	√	√
<b>SHUTTLE</b>	As of 1999	SRS	√	√	√	√
<b>SHUTTLE</b>	As of 1999	IMMOBILISE R	√	√		√
<b>SPIKE</b>	As of 1999	PGM-FI	√	√	√	√



## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>SPIKE</b>	As of 1999	AT	√	√	√	√
<b>SPIKE</b>	As of 1999	ABS	√	√	√	√
<b>SPIKE</b>	As of 1999	SRS	√	√	√	√
<b>SPIKE</b>	As of 1999	EPS	√	√	√	√
<b>SPIKE</b>	As of 1999	IMMOBILISE R	√	√		√
<b>STEP WGN</b>	As of 1999	PGM-FI	√	√	√	√
<b>STEP WGN</b>	As of 1999	AT	√	√	√	√
<b>STEP WGN</b>	As of 1999	ABS	√	√	√	√
<b>STEP WGN</b>	As of 1999	SRS	√	√	√	√
<b>STEP WGN</b>	As of 1999	IMMOBILISE R	√	√		√
<b>STREAM</b>	As of 1999	PGM-FI	√	√	√	√
<b>STREAM</b>	As of 1999	AT	√	√	√	√
<b>STREAM</b>	As of 1999	ABS	√	√	√	√
<b>STREAM</b>	As of 1999	SRS	√	√	√	√
<b>STREAM</b>	As of 1999	IMMOBILISE R	√	√		√
<b>STREAM</b>	As of 1999	BCM	√	√	√	√
<b>TODAY</b>	As of 1999	PGM-FI	√	√	√	√
<b>TODAY</b>	As of 1999	AT	√	√	√	√
<b>TODAY</b>	As of 1999	ABS	√	√	√	√
<b>TODAY</b>	As of 1999	SRS	√	√	√	√
<b>TORNEO</b>	As of 1998	ENGINE	√	√	√	√
<b>TORNEO</b>	As of 1998	AT	√	√	√	√
<b>TORNEO</b>	As of 1998	ABS	√	√	√	√
<b>TORNEO</b>	As of 1998	SRS	√	√	√	√
<b>That's</b>	As of 1999	PGM-FI	√	√	√	√
<b>That's</b>	As of 1999	SRS	√	√	√	√
<b>That's</b>	As of 1999	EPS	√	√	√	√
<b>That's</b>	As of 1999	IMMOBILISE R	√	√		√
<b>VAMOS</b>	As of 1999	PGM-FI	√	√	√	√
<b>VAMOS</b>	As of 1999	AT	√	√	√	√
<b>VAMOS</b>	As of 1999	ABS	√	√	√	√
<b>VAMOS</b>	As of 1999	SRS	√	√	√	√
<b>VAMOS</b>	As of 1999	EPS	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>VAMOS</b>	As of 1999	IMMOBILISE R	√	√		√
<b>VIGOR</b>	As of 1995	ENGINE	√	√	√	√
<b>VIGOR</b>	As of 1995	AT	√	√	√	√
<b>VIGOR</b>	As of 1995	ABS	√	√	√	√
<b>VIGOR</b>	As of 1995	SRS	√	√	√	√
<b>Z</b>	As of 1999	PGM-FI	√	√	√	√
<b>Z</b>	As of 1999	SRS	√	√	√	√
<b>Z</b>	As of 1999	EPS	√	√	√	√
<b>Zest</b>	As of 1999	PGM-FI	√	√	√	√
<b>Zest</b>	As of 1999	AT	√	√	√	√
<b>Zest</b>	As of 1999	ABS	√	√	√	√
<b>Zest</b>	As of 1999	SRS	√	√	√	√
<b>Passport</b>	1996 - 2002	PGM-FI	√	√	√	√
<b>Passport</b>	1996 - 2002	AT	√	√	√	√
<b>Passport</b>	1996 - 2002	ABS	√	√	√	√
<b>Passport</b>	1996 - 2002	SRS	√	√	√	√
<b>ZDX</b>	As of 2010	PGM-FI	√	√	√	√
<b>ZDX</b>	As of 2010	AT	√	√	√	√
<b>ZDX</b>	As of 2010	ABS	√	√	√	√
<b>ZDX</b>	As of 2010	SRS	√	√	√	√
<b>ZDX</b>	As of 2010	EPS	√	√	√	√
<b>ZDX</b>	As of 2010	BCM	√	√	√	√
<b>ZDX</b>	As of 2010	IMMOBILISE R	√	√	√	√
<b>CR-Z</b>	As of 2010	PGM-FI	√	√	√	√
<b>CR-Z</b>	As of 2010	AT	√	√	√	√
<b>CR-Z</b>	As of 2010	ABS	√	√	√	√
<b>CR-Z</b>	As of 2010	SRS	√	√	√	√
<b>CR-Z</b>	As of 2010	EPS	√	√	√	√
<b>CR-Z</b>	As of 2010	BCM	√	√	√	√
<b>CR-Z</b>	As of 2010	IMMOBILISE R	√	√	√	√
<b>ACCORD_CR OSSTOUR</b>	As of 2010	PGM-FI	√	√	√	√
<b>ACCORD_CR OSSTOUR</b>	As of 2010	AT	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
ACCORD_CR OSSTOUR	As of 2010	ABS	√	√	√	√
ACCORD_CR OSSTOUR	As of 2010	SRS	√	√	√	√
ACCORD_CR OSSTOUR	As of 2010	EPS	√	√	√	√
ACCORD_CR OSSTOUR	As of 2010	BCM	√	√	√	√
ACCORD_CR OSSTOUR	As of 2010	IMMOBILISE R	√	√	√	√
ACCORD_CR OSSTOUR	As of 2010	HONDA SMART CARD KEY	√	√	√	√
ACTY VAN	As of 2011	PGM-FI	√	√	√	√
ACTY VAN	As of 2011	AT	√	√	√	√
ACTY VAN	As of 2011	ABS	√	√	√	√
ACTY VAN	As of 2011	SRS	√	√	√	√
ACTY VAN	As of 2011	EPS	√	√	√	√
ACTY VAN	As of 2011	BCM	√	√	√	√
ACTY VAN	As of 2011	IMMOBILISE R	√	√	√	√
ACURA TL	As of 2001	PGM-FI	√	√	√	√
ACURA TL	As of 2001	AT	√	√	√	√
ACURA TL	As of 2001	ABS	√	√	√	√
ACURA TL	As of 2001	SRS	√	√	√	√
ACURA TL	As of 2001	EPS	√	√	√	√
ACURA TL	As of 2001	BCM	√	√	√	√
ACURA TL	As of 2001	IMMOBILISE R	√	√	√	√
ACURA TL	As of 2001	HONDA SMART CARD KEY	√	√	√	√
BALLADE	As of 2012	PGM-FI	√	√	√	√
BALLADE	As of 2012	AT	√	√	√	√
BALLADE	As of 2012	ABS	√	√	√	√
BALLADE	As of 2012	SRS	√	√	√	√
BALLADE	As of 2012	EPS	√	√	√	√
BALLADE	As of 2012	BCM	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>BALLADE</b>	As of 2012	IMMOBILISE R	√	√	√	√
<b>BRIO</b>	As of 2012	PGM-FI	√	√	√	√
<b>BRIO</b>	As of 2012	AT	√	√	√	√
<b>BRIO</b>	As of 2012	ABS	√	√	√	√
<b>BRIO</b>	As of 2012	SRS	√	√	√	√
<b>BRIO</b>	As of 2012	EPS	√	√	√	√
<b>BRIO</b>	As of 2012	BCM	√	√	√	√
<b>BRIO</b>	As of 2012	IMMOBILISE R	√	√	√	√
<b>FIT ARIA</b>	As of 2009	PGM-FI	√	√	√	√
<b>FIT ARIA</b>	As of 2009	AT	√	√	√	√
<b>FIT ARIA</b>	As of 2009	ABS	√	√	√	√
<b>FIT ARIA</b>	As of 2009	SRS	√	√	√	√
<b>FIT ARIA</b>	As of 2009	EPS	√	√	√	√
<b>FIT ARIA</b>	As of 2009	BCM	√	√	√	√
<b>FIT ARIA</b>	As of 2009	IMMOBILISE R	√	√	√	√
<b>FIT HYBRID</b>	As of 2011	PGM-FI	√	√	√	√
<b>FIT HYBRID</b>	As of 2011	AT	√	√	√	√
<b>FIT HYBRID</b>	As of 2011	ABS	√	√	√	√
<b>FIT HYBRID</b>	As of 2011	SRS	√	√	√	√
<b>FIT HYBRID</b>	As of 2011	OPDS	√	√	√	√
<b>FIT HYBRID</b>	As of 2011	EPS	√	√	√	√
<b>FIT HYBRID</b>	As of 2011	BCM	√	√	√	√
<b>FIT HYBRID</b>	As of 2011	IMMOBILISE R	√	√	√	√
<b>FIT HYBRID</b>	As of 2011	IMA(HYBRID)	√	√	√	√
<b>FIT SHUTTLE</b>	As of 2011	PGM-FI	√	√	√	√
<b>FIT SHUTTLE</b>	As of 2011	AT	√	√	√	√
<b>FIT SHUTTLE</b>	As of 2011	ABS	√	√	√	√
<b>FIT SHUTTLE</b>	As of 2011	SRS	√	√	√	√
<b>FIT SHUTTLE</b>	As of 2011	EPS	√	√	√	√
<b>FIT SHUTTLE</b>	As of 2011	BCM	√	√	√	√
<b>FIT SHUTTLE</b>	As of 2011	IMMOBILISE R	√	√	√	√
<b>FIT SHUTTLE HYBRID</b>	As of 2011	PGM-FI	√	√	√	√

## HONDA V10.46 Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>FIT SHUTTLE HYBRID</b>	As of 2011	AT	√	√	√	√
<b>FIT SHUTTLE HYBRID</b>	As of 2011	ABS	√	√	√	√
<b>FIT SHUTTLE HYBRID</b>	As of 2011	SRS	√	√	√	√
<b>FIT SHUTTLE HYBRID</b>	As of 2011	EPS	√	√	√	√
<b>FIT SHUTTLE HYBRID</b>	As of 2011	BCM	√	√	√	√
<b>FIT SHUTTLE HYBRID</b>	As of 2011	IMMOBILISE R	√	√	√	√
<b>FIT SHUTTLE HYBRID</b>	As of 2011	IMA(HYBRID)	√	√	√	√
<b>JAZZ HYBRID</b>	As of 2011	PGM-FI	√	√	√	√
<b>JAZZ HYBRID</b>	As of 2011	AT	√	√	√	√
<b>JAZZ HYBRID</b>	As of 2011	ABS	√	√	√	√
<b>JAZZ HYBRID</b>	As of 2011	SRS	√	√	√	√
<b>JAZZ HYBRID</b>	As of 2011	EPS	√	√	√	√
<b>JAZZ HYBRID</b>	As of 2011	BCM	√	√	√	√
<b>JAZZ HYBRID</b>	As of 2011	IMMOBILISE R	√	√	√	√
<b>JAZZ HYBRID</b>	As of 2011	IMA(HYBRID)	√	√	√	√
<b>SPIRIOR</b>	As of 2010	PGM-FI	√	√	√	√
<b>SPIRIOR</b>	As of 2010	AT	√	√	√	√
<b>SPIRIOR</b>	As of 2010	ABS	√	√	√	√
<b>SPIRIOR</b>	As of 2010	SRS	√	√	√	√
<b>SPIRIOR</b>	As of 2010	EPS	√	√	√	√
<b>SPIRIOR</b>	As of 2010	BCM	√	√	√	√
<b>SPIRIOR</b>	As of 2010	IMMOBILISE R	√	√	√	√
<b>SPIRIOR</b>	As of 2010	HONDA SMART CARD KEY	√	√	√	√
<b>GB-1 EVERUS S1</b>	As of 2011	PGM-FI	√	√	√	√
<b>GB-1 EVERUS S1</b>	As of 2011	AT	√	√	√	√

**HONDA V10.46** Diagnostics List (Note: For reference only)

Car Name	Year	System	Functions			
			Sys. Info.	Read code	Clear code	Data Stream
<b>GB-1 EVERUS S1</b>	As of 2011	ABS	√	√	√	√
<b>GB-1 EVERUS S1</b>	As of 2011	SRS	√	√	√	√

(\*) : Tested;

(?) : Manual on website ([www.x431.com](http://www.x431.com));

Note: The final interpretation of the products belongs to LAUNCH TECH CO., LTD. ;